



# Trusti Pasteur Pro Do's and Do Not's:



Follow these guidelines to enhance the performance and longevity of your Trusti Pasteur Pro.

<b>Do</b> 	<b>! Do Not !</b> 
Use clean quality water to operate.	Use hard or high mineral water.
Keep debris out of the tank.	Allow debris such as straw or bedding to enter the tank.
Check the tank filter regularly and clean as necessary.	Operate the TPP without the tank filter. If the filter is misplaced or damaged, call for a replacement.
Keep water away from the front grey cover. To clean, wipe with a cloth.	Run water over the front cover.
Position your Pasteur Pro in a clean, well-drained, surface, indoors and away from direct sunlight.	Allow the Pasteur Pro to sit in water. The bench or table should be dry to avoid humidity rising around the electronics.
Follow the cleaning protocol.	Leave the Pasteur Pro in an unclean state, this will shorten the lifespan and void warranty.
Use the attachments and fixings provided, or an equivalent type.	Alter the Pasteur Pro in any way, including dismantling the machine and forcing alternative hose connections.
Check for water leaks or drips underneath the machine.	Operate the machine if you see a water leak.
Use a stable 1500W minimum power supply.	Use less than 1500W or fluctuating power.
Place colostrum into the refrigerator or freezer for storage as soon as the selected pre-storage programme is finished.	Leave colostrum sitting in ambient temperature, it will grow bacteria.
Occasionally check for software updates	
Handle colostrum cleanly	
Ensure colostrum bags are always thoroughly clean.	Use unclean bags
Use Antahi colostrum bags	Use other brand bags as these have not been tested and approved.
Read the safeguards	