

Trusti Pasteur Pro Cleaning Protocol



Regular cleaning is easy and will extend the life and energy efficiency of your Trusti Pasteur. Cleaning process involves removing general grime and also descaling to remove mineral deposits.

- Do not use high mineral water, this will damage your pasteuriser, making it inefficient and cause blockages.
- Keep debris such as straw and wood shavings out of the tank.
- Check the tank filter regularly and clean as needed.
- Do not run water over the front cover, this area should be cleaned with a cloth.
- The Trusti Pasteur should be positioned on a dry, well drained location.

Run a clean cycle (steps below) monthly. If you are expecting to not use the pasteuriser for a long time, it is recommended to run a cleaning cycle after its last use and before its resting period.

It is also suitable to put dishwashing powder into the water occasionally, especially recommended if milk leaks into the water. Remember to rinse after cleaning, by filling and draining or by operating the cleaning cycle.

STEPS:

- 1) Remove the stainless-steel mesh filter from inside the tub, clean it and put it back in position.
- 2) To clean, place 1 cup of sodium bicarbonate (baking soda) into the tank and select and run the cleaning programme.
- 3) To descale, place 1 cup of citric acid into the tank and select and run the cleaning programme.

CLEANING RECORD:

January	February	March	April	May	June
July	August	September	October	November	December
January	February	March	April	May	June
July	August	September	October	November	December